

























COMP. HEAD HEAD1HZAS DIESEL  COASTER BUS 11101-17010	CRANK SHAFT CRANK1HZ DIESEL  COASTER 1HZ 13411-17012	CRANK SHAFT CAM1HZ DIESEL  COASTER (97-22) 1HZ 13501-17010	RADIATOR RADT37358DM DIESEL  COASTER 1HZ (99-UP) M/T 16400-17260/61	RADIATOR RADT37354MD DIESEL  COASTER 1HZ (93-UP) M/T 16400-17251
ALTERNATOR AL23934 DIESEL  1HD-FTE COASTER (93-12) 24V 75A 2V 27060-17120	STARTER ST991HZ DIESEL  1HZ, COASTER 4.2L L. CRUISER 3.5/4.2 (90-96) 24V 4.5KW 12T 28100-17020	FUEL INJECTOR FIP1HZ  COASTER 1HZ 22100-17561	FUEL FILTER GFC158 GTR  COASTER 1HZ (17-UP) N04C (11-16) 23303-64010	OIL FILTER PC115 GTR, DIESEL  COASTER 1H-Z (90-UP) 1HD-T (90-04) 90915-30002/03006
CLUTCH COVER CC078 AISIN, CTX084/78  COASTER 1HZ (93-UP) 14B 31210-36220	CLUTCH DISC CD133 AISIN, DTX133  COASTER 1HZ/1HD 4.2L (93-UP) 31250-36500	FAN CLUTCH FC157T AISIN  COASTER 1HZ 4.2L (17-UP) DIESEL LONG NECK 16210-17080	FAN CLUTCH FC099F1N AISIN  COASTER 1HZ 4.2L DIESEL 16210-17070	C BRG SUPPORT CBS31  COASTER BB40/50 HZB50/RZB54 37230-36140
CLUTCH BRG. CB021  COASTER 1HZ/N04C (93-UP) 31230-36200	T. CHAIN COVER TCT003 AISIN  COASTER 1HZ/1HDT 11301-17030	HEAD LAMP TY11N9LDL TY11N9LDR  COASTER (08-UP) LHD LH 81130-36610 RH 81170-36590	KYB SHOCK KY445063  COASTER FRONT OIL (82-UP) 48511-36110/80093	KYB SHOCK KY444178  COASTER REAR OIL (93-UP) ZB50/40
BRAKE PAD FD2052 GTR  COASTER (83-16) N04C/ 1HZ/ 15B 04465-36020	C. MASTER CYL. CMA19 BGF  COASTER (87-22) 5/8" 31420-36130	C. MASTER CYL. CMA03 BGF  COASTER (84-93) 5/8" 31420-36160 31420-26090/1	UNIVERSAL JOINT GUT20JP UJ-389 220-0020  COASTER 1HZ (90-16) 1HD-T (84-93) 2TR-FE (07-16) N04C (04-16) 04371-36020	GASKET OH177 CHG248  1HZ 4.2L COASTER/ L. CRUISER (90-UP) OH 04111-17010 CHG 11115-17010

LONG BLOCK BLOCK1HZLONG  COASTER 1HZ DIESEL	ARM BUSHING Z453 FRT, LOWER REAR  COASTER 1H-Z (93-UP) 15B-FTE (93-06) N04C (04-UP) 2TR-FE (07-16) 48655-36010	BUSHING ZTP2215 FRONT, REAR  COASTER 1HZ, 1HDT (90-93) 3B, 22R (82-93) 90385-23037	BUSHING Z440 REAR, LOWER  COASTER 1HZ (93-UP) N04C (04-UP) 2TR-FE (07-16) 90385-23002	BUSHING ZGR0008 REAR, LOWER/UPPER  COASTER 1H-Z (93-UP) 15B-FTE (93-06) N04C (04-UP) 2TR-FE (07-16) 90385-19009
CENTER LINK SC3500R  COASTER 1H-Z (93-UP) 15B-FTE (93-06) N04C (04-UP) 2TR-FE (07-16) 45450-39215	IDLER ARM IA3551  COASTER 1H-Z (93-UP) N04C (16-UP) 15B-FTE (93-06) 2TR-FE (07-16) 45490-39425	CONTROL ARM SA350 RH SA351 LH  COASTER (97-04) UPPER RH 48601-39025 LH 48602-39025	BRAKE DRUM DR899  COASTER 1H-Z (93-UP) 15B-FTE (93-06) 2TR-FE (07-UP) FRONT 43512-36171	C. ROD CROD1HZ  COASTER 1H-Z (03-22) 13201-17010
POWER STEERING PUMP PSP1HZ  COASTER 1HZ 44320-36240	ALT. FAN BELT FB1395R  COASTER 1HZ (93-UP) HVB50*ALTERNATOR 90916-02330	TIMING BELT TB920 92 TEETH  COASTER 1HZ (93-UP) 13568-17030	PISTON W/RINGS P6100XSTD  COASTER (98-04) 1HZ 6CYL. 4163CC 13101-17100	CAL. REPAIR KIT CK61KIT  COASTER (93-UP) 60.32MM 04479-36020
WHL. CYLINDER WC84  COASTER 1-1/8" REAR RH (93-98) W/FT.DISC 47550-36210	WHL. CYLINDER WC85  COASTER 1-1/8" REAR RH 93-98 W/FT.DISC 47560-36210	WHL. CYLINDER WC86  COASTER 1-1/8" REAR LH (93-98) W/FT.DISC 47570-36210	WHL. CYLINDER WC87 18.85  COASTER 1-1/8" REAR LH (93-98) W/FT.DISC 47580-36210	GLOW PLUG GPT153JP  COASTER (89-UP) 1HZ, 3B, B, 1HD, 1PZ 24V. 19850-58010
WHL. BEARING WB32207  COASTER 1H-Z (93-UP) 15B-FTE (93-06) N04C (04-UP) 2TR-FE (07-16) FRT, OUT 9-00093-172-0	WHEEL BRG WB33210  COASTER (93-UP) FRONT AXLE INNER 90366-50069	WHL. BEARING WB32211  COASTER (93-UP) REAR/OUT 90366-55054	WHL. BEARING WB32212  COASTER REAR/ INNER	HEAD LAMP TY11A6YL TY11A6YR  COASTER (08-UP) RHD LH 81150-36150 RH 81110-36170

AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER
A1526  DAIHATSU DELTA 4Y (87-06), 14B (05-UP) TOYOTA LAND CRUISER 3B 3.4L (89-94) 17801-56010	AF8410  FORD RANGER (03-11) MAZDA B3000 P/UP 3.0/4.0L (03-11) ZZPO-23-603	AF6312  ACURA RDX K23A1 2.3L TB1 (06-12) 17220RWCA00/01	A8512  HONDA 2.4L K24 ACCORD (07-12) CROSSTOUR (12-15) 17220-R40-A00	A2824  HONDA CR-V R20A9/K24 (16-UP) 17220-5PH-A00
AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER
A9612  HYUNDAI ENTOURAGE (06-10) KIA SEDONA (05-06) G6DA 3.8L 28113-4D000	A9610  ISUZU D-MAX (06-12) 2.5L 4JA1/ 4JK1 8-98027-480-0	A520  ISUZU RODEO 4JB1T (89-93) P/UP TFR 4JA1/ 4JB1 (97-03) 8-94334-906-0	A519  ISUZU NPR TRUCKS 4HF1/4HG1 (90-03) 8-97030-325-0	A522  ISUZU ELF 4JG2 (93-07) ELF150 4JG2 (93-97) NISSAN ATLAS (95-02) 8-97084-323-1
AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER
A1760  MAZDA WL-T BONGO 2.5L (95-05) PROCEED (96-99) WLJ5-13-240A	A371 DIESEL  MITSUBISHI FUSO TRUCKS (95-UP) ME294850	A620109S  MITSUBISHI L200 2.5L 4D56 K14/24 (87-97) MS620109S	A3009  MITSUBISHI L200 4D56T (96-01) DELICA 4D56 (94-99)/ 4M40 (94-04)/ 4G63 (94-99) MR204842	A3003  MITSUBISHI CANTER/ROSA 4M50/51 4D33/34 (99-04) ME017246
AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER	AIR FILTER
A2007V  NISSAN KING CAB D22 (98-01) MISTRAL (96-99) TERRANNO R20 (93-06) 16546-7F002	A29002  SUZUKI KIZASHI J24B 2.4L (09-16) 13780-57L00	A137 DIESEL  TOYOTA HIACE 2L (84-89) 17801-64030/54040	A191Y A19048/19075  TOYOTA HILUX 2L/5L/ 2KD (85-06) 17801-54150/80	A15170  TOYOTA AURIS (06-18) AVENSIS (08-15) COROLLA (06-UP) VERSO (09-15) 17801-26020
TRANS. FILTER	TRANS. FILTER	TRANS. FILTER	TRANS. FILTER	TRANS. FILTER
ATF453  HONDA CIVIC 1.6L B16A/ CR-V 2.0L B20B (95-01) INTEGRA 1.8L B18C (91-01) 25420-P56-003	ATF195  HYUNDAI ACCENT 1.5L (99-12) ELANTRA 1.6L (95-01) GETZ 1.3/1.4/1.6L (02-11) KIA CERATO (04-08) RIO G4EE/ED (04-12) 46321-22731	ATF317K  MAZDA FAMILIA 1.3/1.5L (98-03) MPV 2.3L (06-16) MAZ3 (03-11)/ MAZ5 (04-10)/ MAZ6 (02-08) FN01-21-500A	ATF991  MITSUBISHI DIAMANTE F38A 3.5L 6G74 (95-02), GALANT 6G75 3.8L (03-06) MR350441	ATF989  SUZUKI ESTEEM G13BB 1.3L (95-02) 26570-82300

AIR FILTER	AIR FILTER	AIR FILTER	WHEEL BRG	WHEEL BRG
A364 CA4568  ISUZU NPR (86-07) NQR (94-07) NRR (05-16) ME033717 8-94430-250-0	A579 CA9856  ISUZU NPR TRUCK 4HE1/4HF1 (93-UP) 8-97062-294-0	A524  ISUZU NPR (97-07) 8-97190-269-1	WB32210  ISUZU ELF NPR 4HF1/ G1/K1/L1 (93-UP) FRT IN 9-00093-149-0	WB32207  ISUZU ELF NPR 4HF1/ G1/K1/L1 (93-UP) FRT OUT 90366-35105
FUEL FILTERS	FUEL FILTER	FUEL FILTER	OIL FILTER	FAN BLADE
GFC0023  ISUZU ELF NPR5SS 5.20L 4HK1-TCS (14-UP) 16403-89T0C	GFC208A  23303-56030	GFC607  ISUZU ELF NPR (84-98) NKR 4JB1 2.8L (02-UP) TFR 4JA1-T (04-11) 8-94414796-0	PC518  ISUZU NPR/ELF 4HF1/4HE1/4HG1 8-97096-777-0	FAN0003  ISUZU ELF NPR 4HK1 8-97367-381-0
B. MASTER CYL.	B. MASTER CYL.	CLUTCH M. CYL	CL. SLAVE KIT	CL. SLAVE CYL.
BMC956  ISUZU ELF 4HE1-T 4.8L NPR70 (93-95) FRONT DISC, LHD 8-97224-371-0	BMC976  ISUZU ELF 4HE1-T 4.8L NPR70 (93-98) FRONT DRUM, LHD 8-97224-374-0	CMA56 BGF  ISUZU NPR (85-03) 2.8L DIESEL 13/16" 8-94336-888-1	CO006  ISUZU ELF NPR (86-UP) 1" 5-87831-302-0	COA71  ISUZU ELF NPR58 4BE1 (88-90) NPR59 4BD1 (87-90) 8-97032-851-1
ALTERNATOR	ALTERNATOR	ALTERNATOR	ALTERNATOR	KING PIN KIT
AL12097  ISUZU 4BD1 NPR 12V 70A 2V DIESEL 8-94408-365-0	AL12717  ISUZU NPR 4HF1/4HG1/4JB1 24V 60A 3V DIESEL 8-97175-390-1	AL12536  ISUZU NPR 12V 4HE1 4.8/5.2L 110A. 8-97248-297-0	AL12718  ISUZU NPR/ NKR (00-03) 4HF1 24V 80A 8-97351-574-0	KP231  ISUZU NPR/NKR/NHR 30 X 188MM 5-87830-536-0
AC COMP	TURBO	TURBO	STARTER	STARTER
ACC4HK1  ISUZU NPR 4HK1 (05-07) 1GR/12V 145MM 8-97386-349-1	TURBO4JA1T25  ISUZU D-MAX 2.5L 4JA1-T 8-97240-210-1	TURBO4BD2T  ISUZU NPR 4BD2-T (86-91) 8-98732-074-1	ST18960  ISUZU NPR 24V 11T 4BE1/4HF1/4HG1 DIESEL 8-97032-464-0	ST18500  ISUZU 4HE1 NPR (99-06) 12V 3.0KW 11T DIESEL 8-97207-786-0

BRAKE SHOE	BRAKE SHOE	BRAKE SHOE	BRAKE SHOE	BRAKE DRUM
BS4404TW PARKING  ISUZU NPR57 4BC2 (84-93) NPR58 4BE1 (87-90) 9-46200-045-0	BS4443TW PARKING  ISUZU ELF NPR (86-UP) 8-97039-047-0	BS4459  ISUZU NPR (90-UP) REAR 8-97094-504-0	BS4466 PARKING  ISUZU ELF NPR5SS 5.20L 4HK1-TCS (14-UP) 8-97042-934-1	DR682  ISUZU NPR TRUCKS (86-09) 8-97319-055-0
BRAKE PAD	BRAKE PAD	BRAKE PAD	DISC ROTOR	DISC ROTOR
FD4054  ISUZU NPR (04-UP) DYNA/ TITAN 8-97367-539-0	FD4052  ISUZU NPR/NKR/NPS (97-UP) NJR (07-UP) FRONT 8-97168-633-0	FD4049 GTR, D4049  ISUZU NKR/NPR/NPS 4.3/4.6/4.8/5.0/5.2L (99-UP) FRONT 8-97998-075-0	DR975  ISUZU NPR TRUCK (87-98) 8-97095-152-0	DR957  ISUZU NPR TRUCKS (99-UP) 8-97168-631-2
BALL JOINT	C. BRG. SUPPORT	SPRING BSHG.	MOTOR MOUNT	SHOCK BUSHING
BJ5321  ISUZU NPR (93-07) FRONT UPPER L/R 8-97107-328-0	CBS25  ISUZU ELF250 NPR 32MM 5-13710-008-0	Z902  ISUZU TRUCK 08-UP ELF NPR (84-UP) 8-94118588-0	Z407  ISUZU NPR (94-UP) REAR 8-94111-903-0	ZGR0008  ISUZU ELF NPR (90-UP) REAR LOW/UP 90385-19007
WATER PUMP	WATER PUMP	WATER PUMP	WATER PUMP	TIE ROD END
WPI064  ISUZU ELF NPR 4HK1 5.2L (05-UP) 8-97363-478-0	WPI042 NPW  ISUZU ELF NPR 4HF1/4HG1/4HE1T (90-UP) 8-97073-951-Z	WPI925  ISUZU ELF250/150 NPR 4JA1/4JB1 (84-94) 8-94140-341-2	WPI032 GMB  ISUZU NPR 4BD1 4BC2 4BE1 (84-UP) 8-9443-580-0	TR5321L TR5321R  ISUZU TRUCK NPR (97-UP) LH 8-97107-349-0 RH 8-97107-348-0
CORNER LAMP	CORNER LAMP	CORNER LAMP	TAIL LAMP	TAIL LAMP
IZ1518CYL 8-97855-007-0 IZ1518CYR 8-97855-008-0  ISUZU NPR TRUCK (93-03)	IZ1530AL 8-98010-892-0 IZ1530AR 8-98010-891-0 DEPO  ISUZU NPR/ NHR TRUCK (04-06) 12V.	IZ1531AQL 8-97585-173-2 IZ1531AQR 8-97585-172-2 DEPO  ISUZU NPR/ NHR TRUCK (07-UP) 12V.	IZ1907L 8-94257-420-2 IZ1907R 8-94257-417-0 DEPO  ISUZU NPR/ NHR TRUCK (93-03)	IZ1910L LH 93587050 IZ1910R RH 93587050 DEPO  ISUZU TFR KB TRUCK (95-UP) UNIVERSAL